



Doing Our Best to Provide You the Best

TB26257, Rev 2
04/20

VACUUM CONNECTION KIT

#6257

Installation Instructions

1. Remove fitting from brake booster.
2. Slide Demco vacuum line onto side **C** of the tee assembly
3. Insert factory booster fitting into side **B** of the tee assembly.
4. Insert side **A** of elbow assembly into brake booster grommet. It will be helpful to use a small amount of spray silicone.

NOTE: It is still necessary to install the check valve at the operating unit. Please follow the vacuum connection instructions in the operator manual.



4010 320th Street • Boyden, IA 51234
www.demco-products.com • 800.543.3626